



E-mail: sales@bluegene.cc tech@bluegene.cc www.bluegene.cc

Notes for Washing Steps

- 1. Be careful not to touch the bottom of the microplate.
- 2. Washing the plate completely according to the instructions.
- 3. The clapping force should not be too strong. You can pad a towel under the absorbent paper to reduce the impact between the desktop and the microplate. Do not directly contact the bottom of the transparent wells. If the wells get covered with fingerprints or stains, the final results will be affected.

